


Konstrukcja Układów Optycznych

Projekt Rzutnika Multimedialnego




Schemat blokowy procesu projektowania układów optycznych


□ Specyfikacja Optyczna

- Wybór modelu startowego projektu
- Ustawienie optycznych parametrów:
 - wymiar slajdu 24x36 mm,
 - baza ekranu 1500 mm,
 - odległość do ekranu,
 - natężenie oświetlenia 1000 lx,
 - współczynnik transmisji układu optycznego 0.7,
 - lampa halogenowa 150 W.


Wybór rozwiązania



Wariant #1: Klasyczny układ projektora analogowego




Wariant #2: Model projektora cyfrowego



Variant #3: Model projektora cyfrowego wg schematu klasycznego (problem z kontrastem)

Obliczenia wstępne



Model cienko elementowy wybranego rozwiązania

2.9x5.8



$(5.8 \times 1.4) / 2 = 4.1$

$$\frac{\sqrt{24^2 + 36^2}}{2} = 21,6$$

$$E' = \pi \left(\frac{n'}{n} \right)^2 \tau L \sin^2 u'$$

$$E' = 1000 \text{ lx}$$

liczba elem.

5

Hr. pow	1	2	3	4	5
f			100E+20		
d		10			
H	0		21,6		
Alfa		0			
V					
L					
Y	-4,12		0		0
Beta				0,004	
Q					
T					

Niezmennik L-H

Program GABAR

liczba elem. 5

1500/36=41,7

Hr. pow	0	1	2	3	4	5
f				1,00E+20		
d			10			
H	0			21,6		-900,72
Alfa	-0,874485	0				
V						
L						
Y	-4,12		-1,668	0		0
Beta			-0,1668	-0,1668	0,004	
Q				1	-41,7	
T				0		

Niezmennik L-H 3,60288

Screen distance

liczba elem.

5

Hr. pow	0	1	2	3	4	5
f		27,6431	93,93285372	1,00E+20	81,98721	
d	27,6431		10	83,93285372	3500	
H	0	24,17349	24,17348571	21,6	0	-900,72
Alfa	-0,874485	0	0,257348571	0,257348571	0,257349	
V			0	1	1	
L				0	0	
Y	-4,12		-1,668	0	14	0
Beta		-0,149043	-0,1668	-0,1668	0,004	
Q			0,893540975	1	-41,7	
T			-1,191428571	0	3583,933	

Niezmiennik L-H

3,60288

Program GABAR

inter lens
distance

liczba elem.


5

Nr. pow	0	1	2	3	4	5
f		27,6431	93,93285372	1,00E+20	81,96721	
d	27,6431	15	10	83,93285372	3500	
H	0	24,17349	24,17348571	21,6	0	-900,72
Alfa	-0,874485	0	0,257348571	0,257348571	0,257349	
V			0	1	1	
L				0	0	
Y	-4,12	-3,90364	-1,668	0	14	0
Beta	-0,007827	-0,149043	-0,1668	-0,1668	0,004	
Q		0,052515	0,893540975	1	-41,7	
T		-472,5535	-1,191428571	0	3583,933	

Niezmennik L-H

3,60288

Program GABAR



$f' = 27.64$
 $A = 0.87$
 $y = 4.12$

$f' = 93.93$
 $A = 0.26$
 $y = 14$

$f' = 81.97$
 $A = 0.17$
 $y = 21.63$
 $m = -41.7$


Model cienko elementowy

Projektowanie obiektywu

□ Projektowanie obiektywu

- Wybór startowego projektu
- Ustawienie warunków pracy dla projektu startowego
- Vinietowanie
- Dyskusja aberacyjna
- Optymalny defocusing
- Kryteria do oceny jakości układu optycznego
- Spot Diagram
- MTF

Wybór projektu startowego



Numerical Aperture = 0.17

$$\text{Field Angle} = \tan^{-1} \frac{\sqrt{12^2 + 18^2}}{83.93} = 14.45^\circ$$

Definicja systemu (working condition):

EFL = 81.97

m = - 41.7X

Numerical Aperture = 0.17

Field Angle = 14.45 deg

It implies:

$F\# = 2.94$ such a large aperture must be specially considered (spherical and coma aberrations must be corrected)

Field Angle = 14.45 deg, such an angle requires correction of field curvature aberrations (design type: anastigmat must be used)


Wybieramy obiektyw typu Tessar

Parametry systemu:


Numerical Aperture = 0.17

Field Angle = 14.45 deg

'OSLO → Lens → Lens Database'




Surface Data						
✓	17.9					
✗						
?						
Gen	Setup	wavelength	Field Points	Variables	Draw off	Group
Notes						
Lens:TESSAR USP2724992/ BREN... Zoom 1 of 1 Efl 99.973638						
Ent beam radius 17.9000000 object height -3.7000e+07 Primary wavln 0.587560						
SRF	RADIUS	THICKNESS	APERTURE RADIUS	GLASS	SPECIAL	
OBJ	0.000000	1.0000e+08	3.7000e+07	AIR		
1	0.000000	0.000000	21.889797 S	AIR		
2	37.300000	7.500000	18.000000 K	LAK9 C		
3	304.970000	4.600000	18.000000 K	AIR		
AST	0.000000	4.000000	15.075090 AS	AIR		
5	-83.800000	1.600000	16.000000 K	SF16 C		
6	33.500000	8.900000	16.000000 K	AIR		
7	315.960000	1.400000	16.000000 K	BASF5 C		
8	37.200000	10.000000	16.000000 K	LAF3 C		
9	-56.220000	80.871449 S	16.000000 K	AIR		
IMS	0.000000	0.000000	42.000000			




■ Ustawienie warunków pracy układu

Rescale lens 'Scale Lens -> Scale to new focal length'



$f' = 81.97$
 $A = 0.17$
 $y = 21.63$



Po przeskalowaniu sprawdź EFL

TESSAR USP2724992/ BREN... [libtes13] - OSLO Premium Edition

File Lens Evaluate Optimize Tolerance Source Tools Window Help

Surface Data

Gen Setup Wavelength Field Points Variables Draw Off Group Notes

Lens: TESSAR USP2724992/ BREN... Zoom 1 of 1 Efl 81.970000

Ent beam radius 14.676499 Object height -3.0337e+07 Primary wavln 0.587560

SRF	RADIUS	THICKNESS	APERTURE RADIUS	GLASS	SPECIAL
OBJ	0.000000	8.1992e+07	3.0337e+07	AIR	
1	0.000000	0.000000	17.947798	S	AIR
2	30.582872	6.149371	14.758491	K	LAK9 C
3	250.049827	3.771614	14.758491	K	AIR
AST	0.000000	3.279665	12.360310	AS	AIR
5	-68.708973	1.311866	13.118658	K	SF16 C
6	27.467191	7.297254	13.118658	K	AIR
7	259.060705	1.147883	13.118658	K	BASF5 C
8	30.500881	8.199161	13.118658	K	LAF3 C
9	-46.095686	66.307807	13.118658	K	AIR
IMS	0.000000	0.000000	34.436478		

EFL = 81.97

m = - 41.7X

Numerical Aperture = 0.17

Field Angle = 14.45 deg

Specify working condition 'Surface Data -> Paraxial Setup Editor'




Image height = 21.63
 $m = -41.7X$
 $NA = 0.17$
object. dist = 3500 mm

Aberracje są wyznaczane w kierunku mniejszego powiększenia!

■ Winietowanie

Set Lens Drawing Conditions to see if for all of field angles all of the rays are transferred.

Lens Drawing Conditions < Surface Data

Initial distance: 0.000000 Final distance: 0.000000

Horizontal view angle: 240 Vertical view angle: 30

First surface to draw: 0 Last surface to draw: 0 Autodraw: YZ

X shift: 0.000000 Y shift: 0.000000 DXF/IGES view: Unconverted

Apertures: Quadrant Rings: 3 Spokes: 4 Image space rays: Image srf


Draw aperture stop: ☐ off ☒ on Hatch back of reflectors: ☐ off ☒ on

Shaded solid color - Red: 175 Green: 185 Blue: 250

Number of ray fans in lens drawings: 3 Points for aspheric profiles: 41

Frac Y Obj	Frac X Obj	Rays	Min Pupil	Max Pupil	offset	FY	FX	wvn	Cfg
0.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
0.700000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
1.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0

Set rows 2 and 3 to observe vignetting




Winietowanie musi być skorygowane dla obu kątów pola


Ustawienie winietowania




W oknie GW 1 naciśnij przycisk i wybierz opcję meni 'Lens Drawing'



Naciśnij przycisk



Okno do graficznej analizy winietowania



Slider Window

Frac. Y Obj.	0.000000	<div></div>	Step 0.01
Frac. X Obj.	0.000000	<div></div>	Step 0.01
Min. Pupil	-1.000000	<div></div>	Step 0.005
Max. Pupil	1.000000	<div></div>	Step 0.01



Frac Y (X) Obj. – actual tangential (sagital) field of view (normalized to max angle),

Min (Max) – actual down (upper) effective aperture diameter (normalized to max aperture)

Frac Y Obj	Frac X Obj	Rays	Min Pupil	Max Pupil	offset	FY	FX	wn	Cfg
0.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
0.700000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
1.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0

← Actual field of view

Analiza winietowania dla 0.7 pola widzenia





Wiązka promieni nie jest w pełni przetransmitowana przez układ – konieczna analiza winietowania

Frac Y Obj	Frac X Obj	Rays	Min Pupil	Max Pupil	offset	FY	FX	wn	Cfg
0.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
0.700000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
1.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0

← Actual field of view

Analiza winietowania dla 0.7 pola widzenia





Przy użyciu slajderów pełna wiązka promieni jest transmitowana przez układ, weźmy również pod uwagę średnice montażowe
Możemy teraz ustawić parametry winietowania
Mamy do czynienia z winietowaniem nie symetrycznym

Frac Y Obj	Frac X Obj	Rays	Min Pupil	Max Pupil	offset	FY	FX	wn	Cfg
0.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
0.700000	0.000000	3	-0.910000	0.750000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
1.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0

Actual field of view

Analiza winietowania dla 1.0 pola widzenia



Mamy do czynienia z winietowaniem niesymetrycznym

Frac Y Obj	Frac X Obj	Rays	Min Pupil	Max Pupil	offset	FY	FX	wvn	Cfg
0.000000	0.000000	3	-1.000000	1.000000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
0.700000	0.000000	3	-0.910000	0.750000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0
1.000000	0.000000	3	-0.870000	0.620000	0.000000	<input checked="" type="radio"/>	<input type="radio"/>	1	0


← Actual field of view

Total vignetting coefficients for fields:

0.7 – 0.83

1.0 – 0.745

W celu użycia wyznaczonych współczynników przy analizie aberracyjnej musimy ustawić je w oknie 'Surface Data - > Field Points Set Data Editor'



Field Points Set Data Editor < Surface Data

✓ ✗ ?

-0.97


spreadsheet style: ☐ Basic ☒ Advanced

FPT	CF	GP	FBY	FBX	FBZ	FYRF	FXRF	FY1	FY2	FX1	FX2	WGT	SP
1	0	0	0.00	0.00	0.00	0.00	0.00	-1.00	1.00	-1.00	1.00	1.000	
2	0	0	0.70	0.00	0.00	0.00	0.00	-0.97	0.75	-1.00	1.00	1.000	
3	0	0	1.00	0.00	0.00	0.00	0.00	-0.87	0.62	-1.00	1.00	1.000	

Efekt ustawienia winietowania



11.8



Automatyczne ustawienie winietowania

Funkcja 'Vig'

Funkcja wyznacza współczynniki winietowania i wyświetla wyniki. Domyślnie, wyniki są przekopiowane do [field points set](#) i do [Lens Drawing Conditions](#).

Uwaga: Checked apertures are taken into account

We will set 'Checked' setting to aperture radiuses: first and the last one

Surface Data

✓ Select aperture option:
✗ **Checked (K)**

Gen Setup wavelength Field Points Variables Draw off Group Notes

Lens: TESSAR USP2724992/ BREN... Zoom 1 of 1 Efl 81.970000

Image num aper 0.170000 Image height 21.630000 Primary wavln 0.587560

SRF	RADIUS	THICKNESS	APERTURE RADIUS	GLASS	SPECIAL
OBJ	0.000000	3.5000e+03	906.184561	AIR	
1	30.582872	6.149371	14.210000	K	
2	250.049827	3.771614	14.758491		
AST	0.000000	3.279665	11.991208	AS	
4	-68.708973	1.311866	13.118658		
5	27.467191	7.297254	13.118658		
6	259.060705	1.147883	13.118658		
7	30.500881	8.199161	13.118658		
8	-46.095686	68.264292	12.040000	K	
IMS	0.000000	-0.308217	34.436478		


Direct Specification
Not Checked
Checked (K)
Pickup... (P)
Solved (S)
Aperture Stop (A)
Reference Surface (R)
Special Aperture Data (X)

First surface


Last surface


Runing 'vig' command


Step 1: write 'vig' and press 



Step 2: press 'Yes' for copying results to 'Field Points' set and press 



Step 3 : press 'Yes' for copying results to 'Lens Drawing Conditions' set and press 



Step 4: Accept default value 5.0 for 'Enter maximum pupil position to test'

RUN COMMAND 'vig':

>> vig

<< Copy vignetting data to field point set?

>> y

<< Copy new field point data to drawing fans?

>> y

<< Enter maximum pupil position to test?

>> 5.0

SETS PARAMETERS:

*VIGNETTING FACTORS

FPT	CFG	FBY	FBX	FY1	FY2	FXMAX
1	0	--	--	-0.999539	0.999539	0.999539
2	0	0.700000	--	-0.931181	0.724541	0.980700
3	0	1.000000	--	-0.901139	0.585673	0.961303

Results copied to 'Field Point Set'

'Field Point Set' copied to 'Drawing Operating Conditions'


Otrzymany układ

UW 1 - Lens Drawing *

TESSAR USP2724992/ BREN...
FOCAL LENGTH = 81.97 NA = 0.17

UNITS: MM
DES: OSLO

11.8




Field ray is obtained as a gravity center of input beam for maximum field of view


Chief ray

▪ Dyskusja aberracji

'Standard Tools -> Ray Intercept curve Analysis'



Poprzeczne (Lateral) aberracje




1 field : appears field curvature aberration (transverse aberration plot tilt), asymmetrical geometrical vignetting enlarges

0.7 field : appears field curvature aberration (transverse aberration plot tilt), asymmetrical geometrical vignetting

On axis: spherical aberrations
5-th order type
Lateral color (chromatic aberrations) present


LONGITUDINAL
SPHERICAL ABER. (mm)



Longitudinal spherical aberrations (5-th order type)

Longitudinal color (defined for blue - F and red - C wavelengths)


ASTIGMATISM
 $S \times T +$ (mm)



Field aberrations:

Astigmatism and field curvature present and must be corrected, considerable Sagittal Field curvature

Field aberrations




Distortion expressed in % from image size
~0.25 % for full field of view

Lateral color aberration ~ 0.015 mm for
full field of view

➤ Optymalne przeogniskowanie


Ocena jakości powinna zostać wykonana dla płaszczyzny przeogniskowania

Użyj funkcję OSLO: 'Evaluate -> Autofocus -> Minimum on-axis spot size (polychromatic)'



Optymalne przeogniskowanie: -0.2844 mm


'Standard Tools -> Ray Intercept...'



Aberrations at optimal defocusing plane

Compare aberrations with paraxial focus

'Standard Tools -> Ray Intercept...'



Aberration at paraxial focus

▪Kryteria oceny jakości

Expected resolution:

Aberrational spot size (screen)

For visual observation from 3.5 m and human eye angular resolution 1' of arc (0.0003 rad) aberrated spot can not exceed

$$3500 \cdot 0.0003 = 1.05 \text{ mm}$$

At image plane (film slide plane) aberration spot can not exceed

$$1.05 \cdot 0.02387 = \mathbf{0.024 \text{ mm}}$$


where 0.02387 is a transverse magnification

The spot size corresponds to (40 l/mm)


40 l/mm will be used as a criteria for design evaluation

■ Spot Diagram and MTF evaluation

OBJ HT
-906mm




OBJ HT
-634mm



OBJ HT
0mm

0.2



-0.05

-0.025

0

0.025

0.05

FOCUS SHIFT


We get spot of effective size around 0.05 mm, it is too high and should be corrected. Spot size on screen is 2 mm what corresponds to angle aberration 2' of arc and can be acceptable especially that it is fulfilled in whole field of view.

FIELD POINTS

ON-AXIS T+ S×
 -634.3mm T▲ S▼
 -906.2mm T■ S◆
 Ideal ○

WAVELENGTHS

#	$\lambda(\mu\text{m})$	Weight
1	0.588	1
2	0.486	1
3	0.656	1




The MTF plot shows that the lens do not transmit the frequencies above 20 l/mm with acceptable contrast (must be corrected)

'Standard Tools -> Spot Diagram Analysis'

Expected resolution:

Aberrational spot size (screen)
 $3500 \cdot 0.0003 = 1.05 \text{ mm}$

Aberrational spot size (slide)
 $1.05 \cdot 0.02387 = 0.024 \text{ (40 l/mm)}$




Expected resolution:

Aberrational spot size (screen)
 $3500 \cdot 0.0003 = 1.05 \text{ mm}$

Aberrational spot size (slide)
 $1.05 \cdot 0.02387 = 0.024 \text{ (40 l/mm)}$


MTF before defocusing



MTF after defocusing

Autofocus

- Paraxial focus
- Minimum on-axis spot size (monochromatic)
- Minimum on-axis spot size (polychromatic)
- Field-averaged spot size (monochromatic)
- Field-averaged spot size (polychromatic)
- Minimum on-axis RMS OPD (monochromatic)
- Minimum on-axis RMS OPD (polychromatic)
- Field-averaged RMS OPD (monochromatic)
- Field-averaged RMS OPD (polychromatic)



Optimization using

'Generate Error Function -> OSLO Spot Size/Wavefront'

24992/ BREN... [libtes13.len] - OSLO Premium

Optimize Tolerance Source Tools Window Help

Generate Error Function

Singlet...

Error Function Tables

Cemented Doublet...

Operands...

GENII Ray Aberration...

OSLO Spot Size/Wavefront...

Variables...

Slider-Wheel Design...

Aberration Operands...

Generate error function

Field sampling method

☐ Current ☐ Gaussian ☐ Radau ☒ Lobatto ☐ Equal areas ☐ Equal heights

Number of samples 3

Duplicate field samples for negative FBV?

☐ Yes ☒ No

Pupil sampling method

☐ Gaussian ☐ Radau ☒ Lobatto ☐ Grid

Number of aperture divisions in pupil 6.300000

Trace full pupil for symmetric lens

☐ Yes ☒ No

Number of rings (on-axis field point) 5

Number of rings (off-axis field points) 3

Number of spokes (off-axis field points) 3

Generate meridional spokes for off-axis field points?

☒ Yes ☐ No

Error function type

☒ RMS spot size ☐ RMS wavefront error

Color correction method

☒ None ☐ Use all wavelengths ☐ Use CHR/DMD operands

Relative weight of CHR/DMD operands 1.000000

Maximum operand configuration 1

Correct distortion at full field

☐ On ☒ Off

Maximum allowed distortion (percent) 1.000000

Generate edge thickness operands

☐ On ☒ Off

Minimum allowed edge thickness 0.500000

Append to existing error function?

☐ Yes ☒ No

OK

Cancel

Help

Obtained MTF


Expected resolution:

Aberrational spot size (screen)

$$3500 \cdot 0.0003 = 1.05 \text{ mm}$$

Aberrational spot size (slide)

$$1.05 \cdot 0.02387 = 0.024 \text{ (40 l/mm)}$$




Projekt kondensora

□ Design of a condensor lens

- Choosing thin element starting design
- Inserting and specifying Aspheric lens in OSLO
- Evaluation of chosen Aspheric lens
- Adding 2-nd lens to the condenser design
- Setting of working conditions of a starting design
- Vignieting analysis
- Evaluation of the condenser design

➤ Choosing starting design



First element requires at least 3 spherical lenses or one aspheric one (due to the working conditions, especially high numerical aperture)

■ Inserting and specifying Aspheric lens in OSLO

From ThorLabs catalog we find aspheric lens No. AL 4532 $f=32$, $NA = 0.612$


Large-Diameter Aspheric Lenses – Page 4 of 5

AL4532 $f = 32.0\text{mm}$ and 0.612 NA

Specifications

- Effective Focal Length: 32.0mm
- Numerical Aperture: 0.612
- Diameter: 45.0mm
- Scratch-Dig: $60-40$
- Design Wavelength: 780nm
- Clear Aperture (Collimation): 41.00mm
- Clear Aperture (Focusing): 37.30mm
- Aspheric Lens Material: S-LAH64
- Refractive Index (@ Design λ): 1.788
- Abbe #: $V_d=47.3$

NEW



Edge Thickness: 3.12mm
Working Distance: 24.12mm

Aspheric Coefficients

	R	k	A_2	A_4	A_6	A_8	A_{10}
AL4532	23.88	-1.678413	-8.294534E-4	9.229323E-06	-3.656184E-09	1.102823E-12	-6.146323E-16

The closest matching lens from catalog

Aspheric Lens Equation


Lens Design Formula

- Positive radius indicates the center of curvature is to the right
- Negative radius indicates the center of curvature is to the left

$$z = \frac{Y^2}{R \left(1 + \sqrt{1 - (1 + k) Y^2 / R^2} \right)} + A_2 Y^2 + A_4 Y^4 + A_6 Y^6 + A_8 Y^8 + A_{10} Y^{10} + A_{12} Y^{12}$$

Variable Definitions

z	SAG as a function of Y
R	Radius of curvature
k	Conic constant
A ₂	2 nd order aspheric coefficient
A ₄	4 th order aspheric coefficient
A ₆	6 th order aspheric coefficient
A ₈	8 th order aspheric coefficient
A ₁₀	10 th order aspheric coefficient
A ₁₂	12 th order aspheric coefficient



Open New Lens with 2 surfaces

Insert lens parameters: surface radius, thickness, clear radius and glass type (from OHARA catalog S-LAH64)

Surface Data

Conic: Standard asphere

Gen Setup wavelength Field Points Variables Draw On Group Notes

Lens: No name Zoom 1 of 1 EFL 30.304530

Ent beam radius 1.000000 Field angle 5.7296e-05 Primary wavln 0.587560

SRF	RADIUS	THICKNESS	APERTURE RADIUS	GLASS	SPECIAL
OBJ	0.000000	1.0000e+20	1.0000e+14	AIR	
AST	23.880000	14.000000	22.500000 A	S-LAH64 C	A
2	0.000000	22.474557 S	22.500000	AIR	
IMS	0.000000	0.000000	3.0305e-05 S		

Difference between catalog and obtained EFL is due to use different wavelengths, we use 0.587 um instead 0.78 um

Specify conic constant

At surface of radius 23.88 and column 'SPECIAL' press right button, chose 'Polynomial Asphere (A) -> Conic / Toric'

Conic/Toric Data < Surface Data

✓
✗
?

-1.678413

Surface 1

Conic constant: -1.678413

Conic type: Hyperbola

Surface type: ☒ Rotationally symmetric ☐ Cylinder ☐ Toroid


Toric curvature: 0.000000

Aspheric Coefficients

	R	k	A ₂	A ₄	A ₆	A ₈	A ₁₀
AL4532	23.88	-1.678413	-8.294534E-4	9.229323E-06	-3.656184E-09	1.102823E-12	-6.146323E-16

Specify Aspheric coefficients

At surface of radius 23.88 and column 'SPECIAL' press right button, chose 'Polynomial Asphere (A) -> Standard Asphere'




Aspheric Coefficients

	R	k	A ₂	A ₄	A ₆	A ₈	A ₁₀
AL4532	23.88	-1.678413	-8.294534E-4	9.229323E-06	-3.656184E-09	1.102823E-12	-6.146323E-16

➤ Evaluation of chosen Aspheric lens

Setting lens working conditions for infinite conjugation

In window 'Surface Data->Paraxial Setup Editor' we set entrance beam radius 21.63, gauss image height 4.12 and magnification 0 (object at infinity)




The screenshot shows the 'Paraxial Setup Editor < Surface Data' window. At the top, there is a status bar with a green checkmark, a red X, and a yellow question mark. Below this is a text input field containing '21.63'. The main area is a table with three columns: Aperture, Field, and Conjugates. The table contains the following data:

Aperture		Field		Conjugates	
Entr beam rad*	21.630000	Field angle	7.742082	Object dist	1.0000e+20
object NA	2.1630e-19	Object height	-1.3595e+19	Object to PP1	1.0000e+20
Ax. ray slope	-0.713755	Gaus image ht*	4.120000	Gaus img dist	22.474557
Image NA	0.713755			PP2 to image	30.304530
working f-nbr	0.700521			Magnification	0.000000
Aperture divisions across pupil for spot diagram:					17.030000
Gaussian beam	No	1/e ² radius on srf 1: sdgx 1.000000 sdgy 1.000000			

For condenser lens usually we apply criterion :
spot diagram size can not exceed 3 to 10 % of image size, for our case an
image (lamp diagonal) is 8,24 mm, the spot size is to be smaller then 0.8
mm


Open 'Spot Diagram' Window toolbar, and run 'Spot Diagram
vs. All field points'




Recalculate window to 'scale' 0.8

Y FIELD


1



0.7



0




Conclusion:

Obtained spot diagram size on-axis satisfy our criterion, off-axis most of the energy is contained within required circle


■ Adding 2-nd lens to the condenser design

Insert catalog lens from Melles-Griot OSLO catalog, part number MG01LPX167 (EFL 95.3), then using right bottom menu command 'Reverse' obtain following



The lenses must be directed with convexities (typical condenser setup for small magnification) according to aberration correction

Add new surface specifying position of aperture stop (slide position)



For plane convex lens

$$x = \frac{\text{lens thickness}}{\text{refractive index}}$$

Obtained data

Surface Data

15.0

Gen Setup Wavelength Field Points Variables Draw On Group Notes

Lens: No name Zoom 1 of 1 Efl 26.113292

Ent beam radius 21.630000 Image height 4.120000 Primary wavln 0.587560

SRF	RADIUS	THICKNESS	APERTURE RADIUS	GLASS	SPECIAL
OBJ	0.000000	1.0000e+20	1.5777e+19	AIR	
AST	0.000000	3.600000	21.630000 AS	AIR	
2	0.000000	9.700000	20.179357	BK7 C	
3	-49.279000	0.000000	22.500000	AIR	
4	0.000000	15.000000	22.500000	AIR	
5	23.880000	14.000000	22.500000	S-LAH64 C	A
6	0.000000	14.175478 S	22.500000	AIR	
IMS	0.000000	0.000000	4.120000 S		

▪ Setting of working conditions of a starting design

We set: numerical aperture and magnification

- numerical aperture is obtained from specification of aspheric lens:

$$NA = 0.71$$

- magnification is a ratio of condenser afocal system

$$\text{Magnification} = \frac{f_1}{f_2} = \frac{30.3}{95.3} = -0.318$$

Paraxial Setup Editor < Surface Data

0.71

Aperture		Field		Conjugates	
Entr beam rad	19.766192	Field angle	8.636479	Object dist	85.569126
object NA	0.225070	object height	-12.996845	object to PP1	108.489607
Ax. ray slope	-0.728696	Gaus image ht*	4.120000	Gaus img dist	22.453392
Image NA *	0.710000			PP2 to image	34.391206
working f-nbr	0.704225			Magnification	-0.317000
Aperture divisions across pupil for spot diagram:					100.000000
Gaussian beam	NO	1/e^2 radius on srf 1: sdgx 1.000000 sdgy 1.000000			

16.7




Fig. Obtained condenser lens design

Conclusion: Severe vignetting, necessary correction

■ Vignetting analysis

From window 'Lens Drawing' toolbar choose



Complete vignetting analysis for both 0.7 and 1 field angle




Fig. Vignetting Setting for field angle 1




Fig. Vignetting Setting for field angle 0.7

Obtained values are introduced into the field points set (Advanced) and to the Lens Drawing Conditions.

Frac Y Obj	Frac X Obj	Rays	Min Pupil	Max Pupil	offset
0.000000	0.000000	3	-1.000000	1.000000	0.000000
0.700000	0.000000	3	-1.000000	0.880000	0.000000
1.000000	0.000000	3	-1.000000	0.820000	0.000000

Fig. Setting 'Lens Drawing Conditions'

Field Points Set Data Editor < Surface Data

✓
✗ 0.0
?


Spreadsheet style: ☐ Basic ☒ Advanced

FPT	CF	GP	FBY	FBX	FBZ	FYRF	FXRF	FY1	FY2	FX1	FX2	WGT	SP
1	0	0	0.00	0.00	0.00	0.00	0.00	-1.00	1.00	-1.00	1.00	1.000	
2	0	0	0.70	0.00	0.00	0.00	0.00	-1.00	0.88	-1.00	1.00	1.000	
3	0	0	1.00	0.00	0.00	0.00	0.00	-1.00	0.82	-1.00	1.00	1.000	

Fig. Setting 'Field Point Set'

Effect of vignetting correction on ray transfer for considered 3 angles of field of view

16.7



▪ Evaluation of the condenser design

Run spot diagram analysis and recalculate for 'Scale' 0.8




Fig. Spot diagram condenser analysis

Our design meets our demands

Individual projects

Projectors:

Project 1: slide projector

Distance to the screen – 5 m

Slide size – 40 x 40mm

Screen base: 2 m

Project 2: movie projector

Cine film – 16 mm

Distance to the screen – 15 m

Screen base: 4 m

Project 3: movie projector

Cine film – 35 mm

Distance to the screen – 15 m

Screen base: 6 m

Project 4: back projection projector

Distance to the screen – 1 m

Slide size – 24 x 36 mm

Screen base (monitor size 25 inch)

Project 5: micro film projector

Cine film – 16 mm

Distance to the screen – 1,5 m

Screen base (format A3)

Project 6: overhead projector

Distance to the screen – 5 m

Slide size – 24x36

Screen base: 4 m

Project 7: Multimedia projector

Distance to screen: 4m

Slide size – 8,64x15,36

Screen base: 1,5m